

Top Entry Air Swivel for WSJ360

1. Connect mounting bracket to boom using square U-bolt and mounting hardware provided. There are two (2) sets of holes provided to clamp the air swivel in place. Use the holes that clear the vertical to mount the air swivel with the square U-bolt.
2. Attach the air swivel to the top side of the air swivel coupling.
3. Connect the lifting device to the air swivel coupling on the underside of the bracket.
4. Connect the air supply from an overhead source into the air swivel.
5. Rotate the crane to its full degree of rotation in both directions to ensure both air hoses are free from obstruction.
6. Check to make sure all fittings and connections are securely fastened and will not leak.

Refer to drawing WSJ360.TEAS for additional references.